

Software upgrade instruction

1. As the below pictures shown, plug out the original SD card first and copy the latest version of the software to the SD card via personal computer and insert the power supply adaptor to the machine to power on the machine. And press encoder button and the top right button together to enter into doctor mode.



2. Then you can operate as the next steps: Setting->Service->Password 1013, and then insert SD card to the position of the machine and make sure the updated software is copied to the SD card, to press "Upgrade", and then choose "Yes" to confirm for software upgrade. And then wait for software to be updated successfully.

